



SET-UP INSTRUCTIONS

1. To set-up your new Bathing Beauty, attach the Hi-Flex Bathing Hose to the threaded Discharge Port located on the front of the Bathing Pump.
2. Attach the end of the black air tubing to the white port, located on the top of the Air Switch Module.
3. Plug the black GFI Safety Control Box into a three-prong, 110/220 volt outlet. **To avoid possible electrical shock, Do NOT use a two prong outlet.**
4. To turn your Bathing Beauty off/on, press and release the Airbulb.

**We recommend you mount your AirBulb on the front of your tub or wall, this will allow you to turn your Bathing Beauty off/on with your elbow or hip, keeping both hands on the dog. Placing the Airbulb Switch on the floor, can lead to accidentally turning the system on or off.*

*** Warranty is voided if operated without water running through the system ***

✖ WARNING ✖

Bathing Beauty should only be plugged into three-prong grounded outlets to prevent possible, electrical shock.

!! WARRANTY VOIDED !!

- IF UNIT IS OPERATED WITHOUT WATER RUNNING THROUGH IT.
- IF GROUNDING PIN, GFI, OR CARRYING HANDLE IS REMOVED OR MODIFIED.
- IF CONNECTED TO VOLTAGE OTHER THAN 110/220.



Using Your New Bathing Beauty

Your new Bathing Beauty is designed for the **shampoo cycle only**. True cleansing takes place during the rinse cycle. Make sure after bathing, to follow through with a “clean” water rinse utilizing your tub’s existing rinse hose.

1. Make sure the metal water flow valve is turned to the off position (knob pointed 90 degrees away from hose) and hold hose securely in your hand before turning the pump on.
2. Run approximately two gallons of warm water into the tub. Most tubs need at least 1 ½ inches of water at the bottom of the pump. For larger dogs, more water may be needed. Water can always be added to the bath at anytime.
3. Place a minimal amount of your favorite, concentrated shampoo or conditioner, into the water near the bottom of the Bathing Beauty. The shampoo will be pulled into the pump and mixed with water as you use it. *For best results, use shampoo and conditioner in it's **concentrated form**, IE 32:1 or 50:1 dilution rates work best, adjust accordingly.
4. Point the nozzle toward the bottom of the tub and turn on. Slowly open the control valve and water should begin to flow, adjust to desired pressure.
5. With water flowing, holding nozzle close to skin, work through animal's coat with a massaging action. Drain tub and rinse pet with your tub's existing rinse hose.
6. Between baths, remove any hair that has accumulated on the the bottom of pump.



HANVEY
ENGINEERING & DESIGN

**Contact Us For
Further Assistance**

☎ 864.269.2912

Cleaning Instructions

It is recommended to clean your Bathing Beauty once per week or daily when bathing extremely dirty pets. Add a dilution rate of 1 cup of vinegar to 1 gal of water to your tub. Recirculate the pump system for 5-10 minutes. This will remove any dander, soap, or conditioner deposits that may have built up in the system.

*** DO NOT USE BLEACH ***

Troubleshooting Tips

Pump will not start.

Check that the GFI plug/control box is plugged in properly. The GFI may be tripped. A light should be “on” indicating that power is available. If the light is off, hit the reset button to turn the GFI light back on.

If the pump itself feels too hot, run cool water over the pump. The motor will shut off if the unit becomes too hot.

Water flow is changing by itself...high to low to high.

You may have too much shampoo in the water or the water level is too low. Add more water to correct either issue.

The pump comes on but water does not flow.

- 1 - Check to see if there is any hair accumulated over the filter screen on the bottom of pump.
- 2 - With pump turned off and valve open, hold hose straight up above pump to release any air bubbles trapped in hose.
- 3 - Stop the pump ASAP. Open the valve completely then close until it is only partially open. Restart the pump. If it does it again, stop and quickly restart the pump. Also try removing the nozzle from the hose at the silver valve and run water into the hose from your faucet.
- 4 - Clean the stainless steel filter screen on the bottom of pump. Use an old toothbrush or a similar brush to clean any soap build-up that may be on the screen.
- 5 - Remove the screen assembly from the bottom of the pump by removing the four stainless steel screws. Check to see if there is anything on the pump fan that could be causing the problem.